


O1. FORE SHROUDS, TOP MAST SHROUDS & TOP GALLANT SHROUDS


O1. FORE MAST










OI. MAIN MAST










O1. FORE SHROUDS, TOP MAST SHROUDS & TOP GALLANT SHROUDS





O1. FORE SHROUDS, TOP MAST SHROUDS & TOP GALLANT SHROUDS


STEPS:

ratines with the aid of the paper template.

- 1, First tie the shrouds at the fore lower trees in pairs, attach 5mm deadeye at the end. Then make the lanyards using 0.45mm light thread, and finally add the
- 2, Make the top mast shrouds in the same way as the lower shrouds, but using 3mm deadeye and 0.25mm light thread. Don't forget to make the futtock shrouds and ratifies using 0.55mm and 0.25mm dark thread.
- 3, Make the top-gallant shrouds, please note that there won't be ratines for these.




O2. MAIN SHROUDS, TOP MAST SHROUDS & TOP GALLANT SHROUDS



SIDE & FRONT VIEW

O3. MIZZEN SHROUDS, TOP MAST SHROUDS & TOP GALLANT SHROUDS



SIDE & FRONT VIEW



O3. MIZZEN SHROUDS, TOP MAST SHROUDS & TOP GALLANT SHROUDS

STEPS:


three).


- 1, Alike Fore and Main mast, first tie the lower shrouds, but only 4 pairs this time. Note that the deadeyes should be smaller (Φ 4mm), and also using thinner thread.
- 2, The making of the top mast shrouds is also similar to the previous two, apart from the dimension changes, there are only 3 shrouds on each side.
- 3, Make the top-gallant shrouds, please note that there won't be ratilnes for these. And unlike the previous two, there are only two of them on each side (instead of



O4. FORE BACKSTAYS

SIDE, FRONT & TOP VIEW







O4. FORE BACKSTAYS

STEPS:


1, First make the two pairs of topmast standing backstay (the lower two). Let the thread go around the head of topmast head, tie together. Then tie two 3mm deadeye on the end of both two, and connect with the 3mm deadeye on the fore channel.

2, Make the a pairs of topgallant mast backstay (the middle one). Also tie a 3mm deadeye at the ends of the thread, and connect with the 3mm deadeye on the fore channel.

3, Then make a pair of royal backstay. Tie them on the eye pin on the fore channel.



O5. FORE SHIFTING BACKSTAY





O5. FORE SHIFTING BACKSTAY

STEPS:

tie a 3mm double block on each side.


2, Tie a single block on the eye pin on the fore channel using 0.35mm thread, and then connect this block with the double block on the shifting backstay, finally tie the end of the tackle thread onto the bottom of the last (from bow to stern) 5mm deadeye.


1, Make a pair of shifting backstay. First tie the thread at the head of topmast, then




O6. MAIN BACKSTAYS

SIDE, FRONT & TOP VIEW









O7. MAIN SHIFTING BACKSTAY

STEPS:

The steps are very similar between the main and fore backstay & shifting backstay. But please note that there are 4 deadeyes on each side (for backstays). Also the tackle thread of the shifting backstay ends on the bottom of the second last deadeye (instead of the last).





SIDE VIEW




O8. MIZZEN BACKSTAYS & SHIFTING BACKSTAY

SIDE, FRONT & TOP VIEW







08. MIZZEN BACKSTAYS & SHIFTING BACKSTAY

STEPS:


pin on the small channel directly.

- end. Connect with the 3mm deadeye on the small channel.
- 2, Then make the shifting backstay, using 0.45mm thread with 3mm single blocks.
- 3, Finally make the mizzen topgallant backstays. Also one pair, connect to the eye



1, First make the mizzen backstay. There's only one pair, with 3mm deadeye at the







CONTENTS SO FAR



O9. BOBSTAY & BOWSPRIT SHROUDS





O9. BOBSTAY & BOWSPRIT SHROUDS


STEPS:

1, Make two pairs of bobstay using 0.8mm thread. Attach two 4mm heart block at the end. Also tie two heart block on the bowsprit, and connect two pairs of heart block using 0.25mm light thread.


2, Tie a bowsprit shrouds on each side of the ship's bow (on eye pins). Attach a 3mm heart block on each, and tie two heart blocks on the bowsprit, the position of the two small hearts should be behind of the second bobstay. Then also connect these hearts using 0.25mm light thread.




10. BUMKIN SHROUDS







11. FORESTAY & FORE PREVENTER STAY



11. FORESTAY & FORE PREVENTER STAY

STEPS:


1, First tie the collars for the forestay and fore preventer stay. The collars are all doubled. Secure a 4mm and a 5mm heart block onto the collars at the bowsprit, the 4mm block should be at the front and the 5mm should be at the back.


2, Then make the forestay. Get the forestay go around the fore mast head and secure it. Attach a 5mm heart block at the end of the main stay, and connect it with the 5mm heart block at the bowsprit.

3, Repeat the process in a similar way for the preventer stay, but be careful with the diameters of the threads.



12. FORE TOPMAST STAY, FORE TOPMAST PREVENTER STAY, FORE TOPGALLANT STAY & FORE ROYAL STAY





12. FORE TOPMAST STAY, FORE TOPMAST PREVENTER STAY, FORE TOPGALLANT STAY & FORE ROYAL STAY

STEPS:

1, First make the fore topmast stay and fore topmast preventer stay. Tie one side on the topmast trees, let the other side go through the bee on the bowsprit. The fore topmast stay should go through the front hole of the bee on the right (starboard side). The fore topmast preventer stay should go through the back hole of the bee on the left (port side).

2, After going through the hole, tie a 7mm violin (long tackle) block at the end of fore topmast stay, and tie a 6mm violin block at the end of fore topmast preventer stay. Attach two eye pin on the bow, tie a 3.5mm single block using 0.35mm thread on the starboard pin, and tie a 3.0mm single block on the port pin. Use 0.25mm white thread to tie the tackle in between the blocks as illustrated.




12. FORE TOPMAST STAY, FORE TOPMAST PREVENTER STAY, FORE **TOPGALLANT STAY & FORE ROYAL STAY**

STEPS:

3, Tie a 3.5mm single block at the front end of the Jib-boom. Tie one end of the head of fore topgallant stay at the illustrated position, get the other end through the single block that just tied. Then get it going backwards, and tie on the heart block of the preventer stay (as shown on mark (1))

4, Tie the fore royal stay as illustrated.





13. MAIN STAY & MAIN PREVENTER STAY


STEPS:

1, First tie the collar for the main stay. Get the 1.2mm thread through the hole on the gammoning knee, then make the entire thread become a ring. Tie a 5.5mm heart block onto the back end of the ring. Also tie a 4mm heart block at the near bottom of the foremast.

2, Then make the main stay. Get the main stay go around the main mast head and secure it. Attach a 5.5mm heart block at the end of the main stay, and connect it with the 5.5mm heart block at the bow.

3, Repeat the process in a similar way for the preventer stay, but be careful with the diameters of the threads.







14. MAIN TOPMAST STAY & MAIN TOPMAST PREVENTER STAY


STEPS:


1, First make the main topmast stay. Tie a 5.5mm single block on the foremast head. Get the main topmast stay go around the main topmast head and secure it, and get it through the single block. Finally tie a 7mm violin block at the end of the thread.

2, Then make the top preventer stay in a similar way, but the single block for this stay is tied on the mast cheeks. Also get the preventer stay through the smaller single block, and finally tie a 6mm violin block at the end of the thread.

3, Tie two single blocks on the eye pins on the deck behind the fore mast, a 3mm block on the left and a 3.5mm block on the right. Connect the 3.5mm single block with the 7mm violin block from topmast stay, and the 3.0mm single block with the 6mm violin block from the preventer stay. Finally tie both tackles back to themselves (go around the tackle and tie).







15. MAIN TOPGALLANT STAY & MAIN ROYAL STAY

STEPS:

1, First make the main topgallant stay. Tie a 3mm single block on the head of fore topmast head, then tie one end on the main topgallant mast, and get the other side through the single block, let the thread go downwards.


2, Tie a 0.35mm thread on the two eye pins at the lower fore mast trees, and make a small ring on the top thread. Get the main topgallant stay attached the ring on the thread.

3, Make a ring using 0.25mm thread on the head of the fore topgallant mast. First connect the main royal stay with the royal mast, then get through this ring, go downwards, and tie on the back of the foremast stay.





TOPGALLANT STAY



16. MIZZEN STAY, MIZZEN TOPMAST STAY & MIZZEN **TOPGALLANT STAY**


STEPS:

1, Attach the mizzen stay on the mizzen lower trees in the same way as fore & main stay. Tie a 4.5 mm heart block at the end of it, then connect with the heart block on the main mast.


2, Tie a 3.5mm single block on the main mast head, get the mizzen topmast stay through the block, then goes down to the upper deck and tie on the jeer bitts.

3, Make a ring using 0.25mm thread on the head of main topmast head. Get the topgallant stay through this ring, and tie on the back of the main stay.







STEP 10-16





17. FORE YARD JEERS







18. FORE YARD TRUSS PENDANTS
















3D VIEW FOR STEP 20, 21


22. FORE TOPGALLANT YARD HALLIARD


Φ\$30 #L25 Φ\$30




23. FORE TOPGALLANT YARD LIFT









25. MAIN YARD JEERS







26. MAIN YARD LIFT





27. MAIN TOPSAIL YARD TYE & HALLIARD






29. MAIN TOPGALLANT YARD HALLIARD









30. MAIN TOPGALLANT YARD LIFT









31. CROSS JACK SLING







31. CROSS JACK LIFT



32. MIZZEN TOPSAIL YARD HALLIARD







L35)
S30)
L35)
S30)


S 30	


33. MIZZEN TOPSAIL YARD LIFT






34. MIZZEN TOPGALLANT YARD HALLIARD













35. MIZZEN TOPGALLANT YARD LIFT









36. SPRITSAIL SLING & HALLIARD




37. SPRITSAIL LIFT




37. SPRITSAIL LIFT





38. SPRITSAIL TOPSAIL SLING & HALLIARD




38. SPRITSAIL TOPSAIL SLING & HALLIARD









39. SPRITSAIL TOPSAIL LIFT






STEP 17-39











37. SPANKER BOOM SHEET







38. GUY PENDANTS











39. THROAT HALLIARD












40. PEAK HALLIARD




















42. FORE BARCES




42. FORE BARCES







43. MAIN BARCES




44. MIZZEN BARCES




44. MIZZEN BARCES




43. FORE TOPSAIL BARCES














43. MIZZEN TOPSAIL BARCES



43. FORE TOPGALLANT BARCES



















43. SPRITSAIL BARCES




43. SPRITSAIL BARCES




43. SPRITSAIL TOPSAIL BARCES







43. SPRITSAIL TOPSAIL BARCES







STEP 40-60





BURBERRY SEAMLESS FULL PATTREN VECTOR COLLETION OF SEAMLESS PATTREN INSPIRED BY 1980 FASHION.

